
Test Procedure for**TAGGING/LABELING, DOCUMENTING, AND SHIPPING****TxDOT Designation: Tex-701-I****Effective Dates: August 2007–March 2008.**

1. SCOPE

- 1.1 Many of the test methods in this series share the same tagging, labeling, documenting, and shipping steps. This procedure details the *minimum* required steps for all test methods in the 700 series.
 - 1.2 The values given in parentheses (if provided) are not standard and may not be exact mathematical conversions. Use each system of units separately. Combining values from the two systems may result in nonconformance with the standard.
-

2. PROCEDURES

- 2.1 Complete [Form 202](#), "Identification of Material Samples," in duplicate.
 - 2.2 Place the original Form 202 in a Form 517 envelope and securely attach it to the sample. Place other required documents in appropriately sized envelopes and include them with the samples.
 - 2.3 Place a red, white, and blue Construction Division, Material and Pavements Section (CST/M&P) identification sticker on the sample.
 - 2.4 Ship the sample to TxDOT, CST/M&P, Cedar Park Campus Bldg. 51, 9500 Lake Creek Parkway, Austin, TX 78717.
 - 2.5 Retain the copy of Form 202 until CST/M&P issues a test report.
-

3. ARCHIVED VERSIONS

- 3.1 Archived versions are available.